

INSTRUCTIONS FOR REMOVING CHAIR TOP AND SEAT SUPPORT 980, 880, 7000, 710

9. Loosen the set screw from the lock nut at the center of the base assembly (see illustrations below)



10. Turning the nut counter clockwise remove nut from key shield.



11. Remove seat support by pulling up and off of base assembly.

